# IMAGE PROCESSING FUNDAMENTALS

### NGUYỄN HẢI TRIỀU $^1$

 $^{1}\mathrm{B}$ ộ môn Kỹ thuật phần mềm, Khoa Công nghệ thông tin, Trường ĐH Nha Trang

NhaTrang, December 2023

- Package Install
- 2 The basic commands in OpenCV

In this part, you will discover the basic functions in order to load, manipulate and display images. Before starting, you need to install the following libraries

- pip install matplotlib
- pip install numpy
- pip install opencv-python==3.4.8.29

OpenCV is a C++ programming library, with real-time capabilities. As it is written in optimized C/C++, the library can profit from multi-core processing.

- Package Install
- 2 The basic commands in OpenCV

### Read image-video-webcam

# Read image

```
2 img=cv2.imread("path_to_image")
Show image
1 cv2.imshow("output",img)
2 cv2.waitKey(0)# delay to see image
```

If we put 0 into waitKey(0), it means infinite delay. The other values equivalent to many milliseconds.

### Read image-video-webcam

See matrix  $M \times N$ , which represents image in OpenCV

```
1 img=cv2.imread("fig/lena_color.png")
2 print(img.shape)
```

The result returns numpy.ndarray with shape (512, 512, 3), where M=512 rows  $\sim$  height, N=512 columns  $\sim$  width and 3 channels  $\sim$  number of channels. In case of RGB color image, by default of OpenCV, the order of the channels is BGR.

```
(512, 512, 3)
[[[121 133 222]
[121 133 222]
[129 137 226]
```

Trieu Hai Nguyen

## Read image-video-webcam

#### Import and display video

Trieu Hai Nguyen Image Processing BM. KTPM-Khoa CNTT

### Read image-video-webcam

#### Import and display Webcam

```
1 import cv2
2 cap=cv2. VideoCapture(0)# replace it with ID of camera
3 #set specific size for camera object
4 cap.set(3,400)#3: width
5 \text{ cap.set}(4,400) \# 4: height; \#10 \text{ for brightness} \dots
  while True:
       success, img=cap.read() #success return true/false
       cv2.imshow("video",img)
       if(cv2.waitKey(30) & 0xFF==ord('q')): # add the delay & wait
           the keyboard to quit
10
           break
```

If you just have one camera (or laptop), you can put 0 and this will use default camera.

Trieu Hai Nguyen Image Processing BM. KTPM-Khoa CNTT

# Sample code

#### The basic operations on the digital image

```
1 import cv2
2 import numpy as np
3 img=cv2.imread("fig/lena_color.png")
4 img1=np.zeros((img.shape[0],img.shape[1],img.shape[2]),np.uint8)
5 for i in range (img.shape[0]):
6     for j in range (img.shape[1]):
7     img1[i][j]=128-img[i][j]#+-*/
8 cv2.imshow("orignal",img)
9 cv2.imshow("new",img1)
10 cv2.waitKey(0)
11 cv2.destroyAllWindows()
```

#### Addition





(a) *I* 

(b) I + 128

#### Subtraction





(c) I

(d) 128 - I

# Multiplication





(e) I

(f) I \* 128

12 / 15

Trieu Hai Nguyen Image Processing BM. KTPM-Khoa CNTT

#### Division





(g) I

(h) I/2

#### THANKS FOR YOUR ATTENTION!

### Tài liệu tham khảo



#### Fernández, Alberto

Mastering OpenCV 4 with Python, 2019, Packt Publishing Ltd.